


## Objectives

- To learn how to use the CapSense component to detect the position of a finger on a multi-segment slider.
- To learn how to use the UART component, the USB-UART bridge on the Pioneer Kit, and a PC GUI to debug designs.

Requirements	Details
Hardware	<a href="#">CY8CKIT-042</a> PSoC 4 Pioneer Kit
Software	<a href="#">PSoC Creator 2.2 SP1</a> , <a href="#">Bridge Control Panel 1.8</a>
Firmware	Lab 3 Template
Components used	CapSense, UART

## Block Diagram

Figure 1. Lab 3 Block Diagram



## Theory

The goal of this lab is to learn how to use PSoC 4's CapSense component to sense the position of a finger on a linear slider, and use the LEDs to display that position. PSoC 4's dedicated CapSense hardware measures finger presence by measuring the change in capacitance when a finger is introduced to a capacitive sensor, normally a small copper shape on a PCB.


The lab will also demonstrate how to use a UART to transmit the position to a PC by using the USB-UART functionality of the Pioneer kit, and the Bridge Control Panel software that ships

with PSoC Programmer. PSoC 4 contains 2 Serial Communication Blocks (SCBs) that can implement UART, SPI, or I2C traffic. We will use the UART component to implement UART functionality.

## Procedure – Firmware


- 1) Open the PSoC 4 Intro Lab Templates workspace, if it's not already open. You will be presented with a workspace in PSoC Creator containing one template project for each of the labs after Lab 1.
- 2) Set the Lab 3 template project as the active project by right-clicking on it in the Workspace Explorer, and clicking on the “Set As Active Project” option. In its initial state, this project will cycle through mixed RGB colors at a rate of 1 Hz.
- 3) Open the project's schematic by double-clicking on the “TopDesign.cysch” file in the Workspace Explorer. Note that in this schematic, we've included three PWMs and pins, along with the “LED\_RGB” module to allow for easy driving of tri-colored LEDs.
- 4) In the component catalog, under the “Capsense” category, select the “Capsense CSD” component, and drag it into the schematic.
- 5) In the component catalog, under the “Communications” category, select the “UART (SCB mode)” component, and drag it into the schematic. The schematic should look like the one shown in [Figure 2](#).

Figure 2. Schematic With CapSense and UART Placed




- 6) Open the CapSense component customizer by double-clicking on the component. Click “Load settings” to automatically configure the component for the kit’s CapSense slider. Select the file “CY8CKIT-042 CapSense Slider.xml” in the lab template workspace directory and press “Open”.
- 7) Navigate to the “Widgets Config” tab, and click on the “LinearSlider0” widget to examine its settings. These settings are used to configure the CapSense sensors, and are described in detail in the CapSense component datasheet. Press the “OK” button when you are done looking at the settings. This window is shown in [Figure 3](#).

Figure 3. CapSense Widget Configuration Tab



- 8) Open the UART component customizer by double-clicking on the component. Navigate to the “UART Basic” tab to configure the UART settings. Change the value of the “Direction” dropdown to “TX only” to set the UART up for uni-directional communication. Press “OK” to close the GUI and apply changes. The GUI correctly configured is shown in [Figure 4](#).

Figure 4. UART Configuration GUI



- 9) Double click on the “Lab 3 CapSense UART.cydwr” file to open the design wide resources interface.
- 10) On the “Pins” tab, assign the “UART\_1:tx” pin to P4[1], the “CapSense\_1:Cmod” pin to P4[2], and the “CapSense\_1:Sns[0-4]” pins to P1[1] through P1[5], in either ascending or descending order. The completed pin assignment should look something like that shown in [Figure 5](#).

Figure 5. Capsense and UART Pin Mapping

Alias	Name	Port	Pin	Lock
Cmod	\CapSense_1:Cmod\	P4[2] SCB0:SPI:SCLK	22	<input checked="" type="checkbox"/>
LinearSlider0_e0_LS	\CapSense_1:Sns[0]\	P1[1] TCPWM2:N	38	<input checked="" type="checkbox"/>
LinearSlider0_e1_LS	\CapSense_1:Sns[1]\	P1[2] TCPWM3:P	39	<input checked="" type="checkbox"/>
LinearSlider0_e2_LS	\CapSense_1:Sns[2]\	P1[3] TCPWM3:N	40	<input checked="" type="checkbox"/>
LinearSlider0_e3_LS	\CapSense_1:Sns[3]\	P1[4]	41	<input checked="" type="checkbox"/>
LinearSlider0_e4_LS	\CapSense_1:Sns[4]\	P1[5]	42	<input checked="" type="checkbox"/>
	\UART_1:tx\	P4[1] SCB0:I2C:SDA, SCB0:SPI:MISO, SCB0:UART:TX	21	<input checked="" type="checkbox"/>
	Pin_BlueLED	P0[3]	27	<input checked="" type="checkbox"/>
	Pin_GreenLED	P0[2] SCB0:SPI:SS3	26	<input checked="" type="checkbox"/>
	Pin_RedLED	P1[6]	43	<input checked="" type="checkbox"/>

- 11) In the “Workspace Explorer”, double-click the “main.c” file to open it in the code editor.
- 12) Replace the “Change1” line with the initialization code, shown in [Code 1](#).

Code 1. Lab 3 “Change1” Initialization Code

```
CapSense_1_Start();
CapSense_1_InitializeAllBaselines();
UART_1_Start();
```

- 13) Replace the “Change2” line with the Capsense slider position read API, shown in [Code 2](#).

Code 2. Lab 3 “Change2” Capsense Slider Position Read API

```
CapSensePosition = CapSense_1_GetCentroidPos(
CapSense_1_LINEARSLIDER0_LS);
```

- 14) Replace the “Change3” line with the Capsense slider position read API, shown in [Code 3](#). The entire main.c should look like that shown in [Figure 6](#).

Code 3. Lab 3 “Change3” UART Put Char API

```
UART_1_UartPutChar(CapSensePosition);
```



Figure 6. Lab 3 Solution main.c


```

1  #include <device.h>
2  #include <LED_RGB.h>
3
4  void main()
5  {
6      /* Place your initialization/startup code here (e.g. MyInst_Start()) */
7      uint16 CapSensePosition;
8      LED_RGB_Start();
9      CyGlobalIntEnable;
10     CapSense_1_Start();
11     CapSense_1_InitializeAllBaselines();
12     UART_1_Start();
13
14     /* CyGlobalIntEnable; */ /* Uncomment this line to enable global interrupts. */
15     for(;;)
16     {
17         /* Place your application code here. */
18         CapSense_1_UpdateEnabledBaselines();
19         CapSense_1_ScanEnabledWidgets();
20         while(CapSense_1_IsBusy() != 0);
21         CapSensePosition = CapSense_1_GetCentroidPos(CapSense_1_LINEARSLIDER0_LS);
22         LED_RGB_SetColorCircle(255 * CapSensePosition);
23         UART_1_UartPutChar(CapSensePosition);
24         CyDelay(10);
25     }
26 }
27
28 /* [] END OF FILE */
29

```

- 15) Press the “Program” button on the PSoC Creator toolbar to build the project and program your kit. After programming, you should be able to change the color of the tri-color LED by moving your finger up and down along the CapSense Slider.
- 16) Using one of the wires shipped with the kit, connect PSoC 4 pin P4[1] (connector J3 pin 10) with PSoC 5LP pin P12[6] (connector J8 pin 9). This is shown in [Figure 7](#).


Figure 7. PSoC 4 Pioneer Kit UART TX Connection



- 17) Open the Bridge Control Panel software, which is in your Start menu under “Cypress -> Bridge Control Panel”.
- 18) Click on the “Chart” menu, and select “Variable Settings”. Ensure that the first variable is named “Var1”, it’s “Active” checkbox is checked, the “Type” is “byte” and the “Sign” checkbox is unchecked. Press “OK” to close the window. This is shown in [Figure 8](#).



Figure 8. Bridge Control Panel Variable Settings Configuration



The dialog box is titled "Variable Settings" and contains two tabs: "Variables" and "Flags". The "Variables" tab is active, showing a table with 8 rows of variable settings. Below the table are controls for printing packets, axis settings, and scroll rate. At the bottom are buttons for "Load...", "Save...", "OK", and "Cancel".

N	Active	Variable Name	Type	Sign	Scale	Offset	Color
1	<input checked="" type="checkbox"/>	Var1	byte	<input type="checkbox"/>	1	0	Black
2	<input type="checkbox"/>	Var2	byte	<input type="checkbox"/>	1	0	Blue
3	<input type="checkbox"/>	Var3	byte	<input type="checkbox"/>	1	0	Red
4	<input type="checkbox"/>	Var4	byte	<input type="checkbox"/>	1	0	Lime
5	<input type="checkbox"/>	Var5	byte	<input type="checkbox"/>	1	0	Blue
6	<input type="checkbox"/>	Var6	byte	<input type="checkbox"/>	1	0	Black
7	<input type="checkbox"/>	Var7	byte	<input type="checkbox"/>	1	0	Magenta
8	<input type="checkbox"/>	Var8	byte	<input type="checkbox"/>	1	0	Olive


Print packet every

Scroll

☒ AxisX is a count      ☒ Auto Range of AxisY  
☐ AxisX is a time      Min  Max


- 19) In the editor tab, select the KIT-042 COM port in the “Connected I2C/SPI/RX8 Ports:” list at the bottom of the window. It should be the highest numbered COM port in the list. The box below the ports list should turn green and say “Connected”.
- 20) In the editor text box, enter the RX8 packet instruction “RX8 @Var1”. With the cursor still on the line that you entered, press the “Repeat” button. Hex bytes should begin to appear in the console below the editor. Move your finger across the CapSense slider and watch the values change. It should look like the image shown in [Figure 9](#).

Figure 9. Bridge Control Panel Data Transmission



21) Click on the “Chart” tab, and observe the values being charted over time. If you want to clear the graph and start over, Press the “Stop” button followed by the “Repeat” button. When sweeping your finger across the slider, the chart should look like that shown in Figure 10.

Figure 10. Bridge Control Panel Chart Interface



## Conclusion

- You have successfully implemented a CapSense slider and UART communication on your PSoC 4 Pioneer Kit. You have also learned how to use the Bridge Control Panel to communicate with the Pioneer Kit, and graph the communicated data.

## Stretch Goals

- Retain the last color when the finger is removed from the CapSense slider.
  - In this lab, we don't examine the CapSense slider position to ensure that it isn't returning a "no finger" code, so the slider turns red when that code is returned.
  - The "CapSense\_1\_GetCentroidPos()" API returns 0xffff when no finger is detected. If this value is detected by firmware, the LED color can be left alone, and the last detected position's color will remain on the LEDs, even when the finger is removed.
- Transmit the whole 16-bit variable "color".
  - In this lab, we shifted the 16 bit variable down by 8 bits and transmitted only the most significant byte (MSB).
  - We could transmit both bytes by masking them individually, and using a control character to indicate coherency.
  - In Bridge Control Panel you will need to configure your variable to be an "int" instead of a "byte", receive both bytes of data, and interpret the packet including the control character. An RX8 command for this would look something like "RX8 [h=43] @1intColor @0intColor" if the control character was hex 0x43 (character 'C').
- Implement bidirectional communications
  - In this lab, we only implemented single direction communication from PSoC 4 Pioneer Kit to the PC.
  - Try implementing communication from the PC to the Pioneer Kit, perhaps setting the LED color using Bridge Control Panel.

Document Revision History

Revision	By	Description
01	MAXK	First Release